

SRL & SRL ADAPTERS




Adapter for Miller SRL
(MR50G, MR50SS, MR40K)
IN-2153



Miller SRL
50' galvanized cable
MR50G
50' stainless steel cable
MR50SS
100' galvanized cable
MR100G
100' stainless steel cable
MR100SS




Adapter for Miller SRL
(MR100G, MR100SS)
IN-2050



Adapter for Protecta SRL (AD515CG)
IN-2152



Protecta SRL
50' galvanized cable
AD515CG



Adapter for North bracket FP6610/15 to
fit North SRL (FP2/415GR(SR)) and Miller
Man Handler
IN-2191



North SRL
50' galvanized cable 3/16" or stainless
steel cable 3/16"
FP2/415GR (SR)
110' galvanized cable 3/16" or stainless
steel cable 3-16"
FP3/433GR (SR)



Adapter for North bracket FP6610/33 to
fit North SRL (FP3/433GR(SR))
IN-2090



Bracket for North SRL (FP2/415GR(SR))
FP6610/15
Bracket for North SRL (FP3/433GR (SR))
FP6610/33



Adapter for Aearo SafeWaze SRL
IN-2079



DBI SRL
50' galvanized cable 3/16"
3400115
50' stainless steel 3-16"
3400108
85' galvanized cable 3/16"
3400311
85' stainless steel cable 3-16"
3400309
130' galvanized cable 3/16"
3400509
130' stainless steel cable 3-16"
3400508